


The repair instructions describe replacing the

- winch handle

in the *Easy Sun* PARASOL Hanging sunshade.

These repair instructions are intended only for persons with experience of using the tools required. Please read the instructions carefully through before working. Damages caused by non-observance of the instructions are excluded from any liability and guarantee


Included in delivery



- ① One winch handle
- ② Grub screw with Allen key
diameter across flats (SW): 4 mm

Tools required

- ▣ Allen key
Diameter across flats (SW): 4 mm.



Safety note



Caution: Risk of accidents!

- Only replace the winch handle when the sunshade is closed.

Installation

- ◇ Release grub screw with Allen key (SW 4 mm).
- ◇ Pull winch handle out of location hole.
- ◇ Insert new winch handle into location hole.
The recess in the handle must face the grub screw.
- ◇ Insert new grub screw and tighten.
When tightening, ensure that the grub screw engages exactly into the recess.



Note

If the grub screw is overtightened the Allen screw can be damaged.

